

You can read the recommendations in the user guide, the technical guide or the installation guide for PHILIPS FWM377. You'll find the answers to all your questions on the PHILIPS FWM377 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

> **User manual PHILIPS FWM377 User guide PHILIPS FWM377 Operating instructions PHILIPS FWM377 Instructions for use PHILIPS FWM377 Instruction manual PHILIPS FWM377**



Philips MP3 Mini Hi-Fi System FWM377

Rip and play music instantly

for non-stop enjoyment

For unlimited music enjoyment, the FWM377 offers a 3-CD changer, 30 hours' non-st playback and the ability to rip all your music—from CDs, tapes and tuner—directly to a USB device. Plus, Max Sound and Dynamic Bass Boost ensure great sound!

- intinuous enjoymen of your favourite music.
 disc changer for WMA-MP3-CD music playback
 ip music from CDs, radio and cassette onto a USB device
 bours of MP3-CD music playback
 igail anning with 40 pre-set stations for extra convenience
 tereo cassette deck

PHILIPS sense and simplicity



Manual abstract:

MP3 Mini Hi-Fi System FWM377/05 Specifications Sound · Total Sound Power (RMS): 240 W · Output Power: 480 W music power · Sound Enhancement: MAX Sound, Dynamic Bass Boost 3 steps, Digital Sound Control 4 modes, Incredible Surround · Tuner Enhancements: Auto Store, Easy Set (Plug and Play) RDS: News, Programme Type, Radio Text, RDS Clock Set, Station Name Connectivity · · · · Loudspeakers · Main Speaker: 2-way, 5.25" woofer, 2" tweeter, Bass Reflex Speaker System · Number of Loudspeakers: 2 · Loader Type: 3 CD Carousel · Number of Discs: 3 · Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD · USB Direct Modes: Delete, Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop · Disc Playback Modes: Repeat/one/disc/ programme, Shuffle Play, 40-Track Programmable · Number of decks: 1 · Cassette Deck Technology: Mechanical · Cassette Playback Modes: Automatic Stop · Recording Media: USB device, Tape · USB recording modes: Instant record, Programmed tracks, Schedule radio programme, Single disc, Single track · USB recording sources: Aux, CD, Tape, Tuner · Tape Recording Enhancement: CD Synchro-Start Recording Aux in: Line-in Headphones: 3.5 mm Microphone: Microphone socket Other connections: FM Antenna, MW Antenna USB: USB host Audio Playback Convenience Alarms: CD Alarm, USB alarm, Radio Alarm, Sleep timer · Clock: On main display · Display Type: FTD · Indications: DIM mode · Karaoke: MIC volume · Eco Power Standby: 1 watt Accessories Audio Recording · Included accessories: FM/MW Antenna, Batteries for remote control, Quick Use Guide · Remote control: 23-key with 2 x AA batteries · Guarantee booklet: Global version · User Manual: English · Set dimensions (W x H x D): 265 x 310 x 384 mm · Main speaker dimensions (W x H x D): 273 x 310 x 204 mm · Packaging dimensions (W x H x D): 640 x 413 x 496 mm · Weight incl. Packaging: 14.9 kg Dimensions Tuner/Reception/Transmission · Auto digital tuning · Station presets: 40 · Tuner Bands: FM, MW Power · · Power supply: 200-240 V, 50 Hz · Standby power consumption: [1 W Issue date 2010-08-24 Version: 3.0.9 © 2010 Koninklijke Philips Electronics N.V. All Rights reserved. Specifications are subject to change without notice.

Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners. www.philips.

